

SM2329

Indirect Venting Goggle

Product Datasheet

OUR REF CODE: 204

PRODUCT DESCRIPTION

Indirect vent anti-fog goggle. Light-weight and extremely durable. Individually packed for convenience. Suitable for protection from average speed impacts and liquid splashes as well as large dust particles.

LENS AVAILABLE: CLEAR

AVAILABLE SIZES: ONE SIZE

PACKAGING: Individual polybag

Per Box: 20

Per Case : 200
(10 boxes of 20 goggles)

NOTE: Eye protection is only effective if correctly selected, fitted and worn for the complete period of exposure to hazards - Read ALL instructions and warnings carefully before use and consult a professional.



CLEAR LENS,
Black or Yellow adjustable head strap

Technical Details

MEETS:
EN 166:2001
PERSONAL EYE PROTECTION

Complies with the requirements of the European Standard EN166:2001 "Personal Eye Protection"

Lens

EN 166 1 B Suitable for continuous use (Class 1 optical)

Average energy impact (resists a 6 mm, 0.86g ball bearing at 120 m/s)

Frame

Suitable for chemical splashes and large dust particles

Instructions for use:

- Inspect the goggles carefully before use and discard if damaged in any way.
- Inspect the goggles at regular intervals. If the frame has become brittle or there is any damage to the goggles leave the area of hazard and replace the goggles.
- There are no user replaceable parts available for this model.

Additional Information:

- **Cleaning:** Clean with warm soapy water and dry with a soft non abrasive cloth.
- **Storage:** When not in use this product should be stored in a clean dry poly bag in a cool place out of direct sunlight and away from solvents, solvent vapours or corrosive materials. Maximum product life 2 years.
- **Damage:** This product should be carefully inspected before use and discarded if damaged in anyway whatsoever.
- **Material Declaration:** No parts which are in contact with the wearer are made from materials known to cause skin irritation.
- **Chemicals:** Certain chemicals may have a detrimental effect on contact with this product. If in doubt please check with your supplier.
- **Disinfection:** The parts of this product in contact with the skin should be disinfected periodically (at least every 3 months) with a suitable disinfectant.
- **WARNING:** This product offers no protection against IR radiation. This product offers adequate protection against UV sun radiation but should not be used against hazardous levels.