

T8000 Self-Contained Open Circuit Breathing Apparatus Quick Start Guide

Safety Check



1 Open the cylinder valve completely in counter-clockwise direction. Observe the pressure gauge until the reading surges to 280 Bar.



2 Close the cylinder valve clockwise (not too tightly). Gently press the yellow by pass button on the demand valve to release. Check the reading until the pressure gauge drops to 50 Bar and the whistle makes a sound.

Wear the apparatus



1 Lift the apparatus with the back of your hands and put it on your back.



2 Pull the ends of the straps until the apparatus is suspended comfortably on your lower back.



3 Fasten the buckle at your waist.



4 Tighten the strap at your waist.



5 Place your chin in the chin cup and pull the straps over your head.



6 Adjust the head harness strap from top to bottom until it fits properly.



7 Place the palm over the inhalation port, inhale and hold your breath for a few seconds. The facepiece should collapse on your face without leaking.



8 Attach the demand valve on the full face mask Air Klic coupling.

Take off the apparatus



1 Release the demand valve by pressing both Air Klic buttons (air supply will stop automatically).



2 Unfasten the head harness to remove the breathing mask from top to bottom.



3 Press the back button of the belt buckle to unfasten the waist strap.



4 Detach the belt of the back-pack.



5 Close the cylinder valve. Press the yellow by pass button of the demand valve to purge the system until the pressure gauge reads 0 Bar.

Warning:

This donning poster is for reference only. Please read the operation manual for more detailed instructions. Only those who have accepted training are entitled to carry out the operation. For more information, please contact your local distributor.